



NO MEM PRO

Model PRO99

Rechargeable Nickel-Metal Hydride Batteries and Charger

**Important Safety Instructions are included.
Please read the entire manual before use.**

Owner's Manual

Thank you for purchasing the NoMEM PRO Battery System. Please read this manual carefully. It contains important operating instructions for your NoMEM PRO Rechargeable Battery System. This PRO99 charger will quickly and efficiently charge all AA, AAA and 9V size Nickel Cadmium (NiCd) or Nickel-Metal Hydride (NiMH) batteries.

Warning:

- Batteries are not charged as shipped. Must be charged prior to first use.
- Charge only NiCd or NiMH batteries on this charger.
- Do Not mix NiCd and NiMH batteries together when charging or using. Keep all NiMH batteries and NiCd batteries separate.
- Use only NoMEM PRO or other proper NiMH compatible charger to recharge NoMEM PRO batteries.
- Batteries may leak or explode causing personal injury if inserted improperly, disposed of in fire, mixed with other battery types, or short circuited.

CHARGING INSTRUCTIONS

AA and AAA Size (Automatic Quick Charge)

1. Remove piece of cardboard out from between batteries and contacts.
2. Slide the battery type switch to the proper position for charging either "Ni-MH" for NoMEM PRO or other Nickel-Metal Hydride batteries, or to "Ni-Cd" to charge Nickel Cadmium batteries. Insert 2-4 AA or AAA batteries into the charger.
3. Plug the charger into any typical household outlet. The CH1 and/or CH2 indicator LED's will glow Red to show charging is taking place for the batteries installed under them.
4. After the proper charge time, the LED's will change from Red to Green to indicate that the charge is complete and batteries are ready for use. The charger will switch to "trickle" mode to keep the batteries at full.
5. Remove batteries and unplug charger once charge is complete. Do not leave batteries in charger for extended periods of time OR when the charger is not plugged in. Unplug the charger when not in use.
6. Begin again at Step-2 to charge the next set of batteries.

CHARGING INSTRUCTIONS (continued)

9 Volt Size (Manual "Overnight" Charge)

1. Connect one or two 9V NiCd or NiMH type batteries to the charger and the red LED in the center will light.
2. Depending on the capacity of the 9V battery to be charged, leave the battery on the charger for 10 – 15 hours according to the table below. The LED will stay on even after the charge time has been reached. Remove the battery which is now ready to use. Unplug the charger when not in use.

CHARGING TIMES:

3 hours – NiCd
8 Hours – NiMH
9V Battery – 110mAh (10 hours), 150-160mAh (15 hours)

CAUTION:

Do not overcharge the batteries. For indoor use only. This NoMEM PRO charger is intended for use with Nickel-Metal Hydride and Nickel Cadmium batteries only. Attempting to charge any other type of battery may cause personal injury and damage to the charger. Never charge NiMH and NiCd batteries at the same time.

Warranty

NoMEM PRO chargers are warranted to be free of manufacturing defects for two years from the original date of purchase. If, during the warranty period, any part fails to function properly under normal use because of manufacturing defects or workmanship, it will be repaired at no charge for parts and labor or, at our option, the product will be replaced. The following is excluded: damages from delay or loss of use of equipment, or damaged batteries, malfunctions resulting from misuse, tampering, unauthorized repairs, modifications, or accident. To obtain warranty service, package the unit and its accessories carefully using ample padding material to prevent damage in transit and ship it prepaid and insured to:

LENMAR ENTERPRISES INC. USA
4035 VIA PESCADOR
CAMARILLO, CA 93012

When sending in product for service, your package should include evidence of date and place of purchase. Enclose \$7.50 for shipping and handling for addresses in the U.S. For outside the U.S. and Canada, freight will vary depending upon ship to address.

For further information contact
Lenmar Enterprises, Inc.
Product Service Department
Phone: (805) 384-9600
E-mail: sales@lenmar.com
Visit Our Web Site at: www.lenmar.com